

## **NETWORK SYSTEM NAME**

When you have more than one Antipodes in your network you will want to give them different names, so that you can open the correct GUI for the one you want to configure.


At the Antipodes GUI, click on 'Settings' and then 'System Settings':



Click on '**Network**' and type in the new System Name (max. 20 characters). It is advisable to use only lower-case letters and numbers without spaces; you can use hyphens or underscore symbols.



## Click 'Save Changes':



Then reboot the Antipodes (System tab).

Even with the names changed, you will be able to open the most recently booted Antipodes by browsing to **myantipodes.com**.

