

4.1 Setup Roon Ready

At the Antipodes GUI:

- Select the 'Settings' menu item
- Click on the 'Roon Ready' icon

This will open the screen shown below. Now:

- Select the correct output driver

- Select how you want to control volume (if you will use your preamplifier select 'None')
- Select how your DAC should receive DSD files.
- Click on 'Save Changes'.

You can now proceed to Section 5 to setup remote control of the Roon Server application.

